


# Fantasia

Desk Fans

## Retro Desk Fan

### Instruction Manual





### Please Read and Save These Instructions

#### RULES FOR SAFE OPERATION

- Never insert fingers, pencils, or any other object through the grill when fan is running.
- Disconnect the fan when moving from one location to another.
- Be sure the fan is on a stable surface when operating to avoid overturning.
- DO NOT get the fan wet; it may create an electrical safety hazard.

#### OPERATION

- Plug power lead into wall outlet.
- The switch on the back of the fan controls on/off and high and low speed settings



Thumb Screws

- Adjust the tilt of the fan by releasing the thumb screws at the side of the fan. Adjust to the required direction and re-tighten the thumb screws

## CLEANING AND MAINTAINENCE.


- Lightly dust. Do not use abrasive cleaners.
- Regularly inspect the cable for any damage.

## LIMITED WARRANTY

- Fantasia Distribution Ltd warranty this product, for 1 year from date of purchase, is free from defects in materials and workmanship. The limited warranty does not cover damage resulting from commercial use, misuse, accident, modification or alteration.
- To claim you must send your product to the address below and provide proof of purchase.
- All transportation costs are the responsibility of the consumer.
- The limited warranty does not effect your statutory rights.

## PLUG REPLACEMENT

- The appliance must be connected to a 240 volts 50 Hz AC supply by means of a three pin socket.
- The appliance is supplied with a rewirable 13 amp 3 pin plug fitted with a 3 amp fuse. Should the fuse require replacement, it must be replaced with a fuse rated at 3 amp and approved to BS1362.
- If the mains plug is unsuitable for the socket outlet in your home or is removed for any other reason, then the cut off plug should be disposed of safely to prevent the hazard of electric shock.
- There is a danger of electric shock if the cut off plug is inserted into any 13 amp socket outlet.



The wires in the mains lead on this appliance are coloured in accordance with the following code:

Green and Yellow – Earth

Blue – Neutral

Brown – Live

## CONFORMITY

- This product is CE marked to denote conformity with Directives 73/23/EEC (Low Voltage) and 89/336/EEC (Electromagnetic Compatibility), as amended.
- Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.

